

Printer Specifications

Printing

- Printing method:** Laser beam scanning and dry electrophotographic process
- Resolution:** 300 X 300 dpi
- Printing speed:** Up to 10 pages per minute (letter or A4) (depending on the font and quantity of data)
- First print:** Less than 18 seconds with A4 or letter
- Warm-up time:** 70 seconds or less at normal temperature

Printer modes..

- HP LaserJet series III emulation
- ESC/P 24-pin printer emulation (LQ-2500)
- ESC/P 9-pin printer emulation (FX-800/1000, FX-86e/286e)

- IC card slots:** 2 slots for identity or font cards
- Slot A holds identity or font cards
 - Slot B holds font cards only

- Cartridge slot:** 1 slot for font cartridges

- Resident fonts:** Depends on the printer mode

- External fonts:** Optional fonts provided with font cards or cartridges
Download fonts

Paper and paper delivery

Paper Specifications

- Types:**
- Plain paper
 - Special papers:
 - Labels
 - Envelopes
 - Transparencies
 - Colored paper
 - Cardstock

Epson does not recommend or guarantee any particular brand of paper. Because paper characteristics are subject to change by individual manufacturers, it is your responsibility to ensure the quality of paper used with the printer.

- Paper weight:** Plain paper: 60 to 90 g/m², 16 to 24 lb
Card stock: 90 to 157 g/m², 24 to 42 lb

Paper sizes:

Paper:	Type	Size
	A4	210 X 297 mm
	AS	148 X 210 mm
	B5	182 X 257 mm
	Letter	8.5 X 11 inches
	Half-Letter	5.5 X 8.5 inches
	Legal	8.5 X 14 inches
	Government Letter	8.0 X 10.5 inches
	Government Legal	8.5 X 13 inches
	Executive	7.25 X 10.5 inches
	F4	210 X 330 mm

Envelope:	Monarch	7/8 X 7 1/2 inches
	Commercial 10	4 1/8 X 9 1/2 inches
	DL	110 X 220 mm
	C5	162 X 229 mm

Printable area:

Depends on the printer mode.

Range of paper width and length:

	Width	Length
Paper cassette	Size of your standard cassette	Size of your standard cassette
Manual feed	86 to 216 mm (3.4 to 8.5 inches)	140 to 356 mm (5.5 to 14 inches)

Paper feed alignment and direction:

Center alignment for all sizes

Paper feed: Automatic or manual feed

Input paper supply (75 g/m² or 20 lb paper):

250 sheets
250 additional sheets with optional lower paper cassette unit installed
several envelopes

Paper eject: Face-up or face-down

Paper eject capacity (75 g/m² or 20 lb. paper):

Face-down **150** sheets
 Face-up 50 sheets with optional face-up output tray

Consumable products**Long life imaging cartridge (S051009):**

Storage temperature:



0 to **30 °C (32 to 86 °F)**

Storage humidity:

30 to a5 % RH

Shelf life: **18** months after production

Life: Up to 8000 pages under the following conditions:
 Letter- or **A4-size** paper, continuous printing, and
 5% print ratio.



The number of pages you can print with an imaging cartridge varies depending on the type of printing. If you print a few page at a time or print dense text exceeding the 5% print ratio, your cartridge may print fewer pages.

Ozone filter H91aa7):

Needs to be replaced every six months.

Mechanical

Dimensions and weight:

Height:	266 mm (10.5 inches)
Width:	477 mm (18.8 inches)
Depth:	383 mm (15.1 inches)
Weight:	18 kg

Durability: **5** years or **300,000** sheets, whichever comes first

Electrical

	120 V model	220/240 V model
Voltage	90 V to 132 V	198 V to 264 V
Rated frequency	50 Hz to 60 Hz ± 3 Hz	50 Hz to 60 Hz ± 3 Hz
Power consumption	Less than 850 W	Less than 850 W
Insulation resistance	2 M Ω minimum	2 M Ω minimum
Dielectric strength (between AC line and chassis)	1000 VAC rms for one minute or 1200 VAC rms for one second	1500 VAC rms for one minute or 1650 VAC rms for one second

Note: Check the label on the back of the printer for the voltage of your printer.

controller hardware

CPU: **68000, 16.67 MHz**

RAM: 1.0 MB (expandable up to 7.5 MB)

Environmental

Temperature: Operation: **10 to 35 °C (50 to 95 °F)**
 Storage: 0 to 35 °C (32 to 95 °F)

Humidity: Operation: **15 to 85 % RH**
 Storage: 30 to 85 % RH

Altitude: 2500 meters (8200 feet) maximum

Options

The Lower Paper Cassette Unit


The optional lower paper cassette unit is an automatic sheet feeder that fits directly beneath the printer. It houses **the** adjustable paper cassette, which holds up to **250** sheets of paper to supplement the standard paper cassette's **250-sheet** capacity.

With the optional cassette installed, you can load two different sizes of paper in your printer at once: one in the lower cassette and the other in the standard cassette. You can also use the SelecType INPUT AUTO setting to use both cassettes and print up to 500 sheets of the same size paper.

Installing the lower paper cassette unit


If you purchased your printer and lower paper cassette unit at the same time, first set up your printer and then run a print test. Then, when you are sure the printer is working properly, install the optional cassette unit.

1. Turn off the printer.
2. Unplug the printer's power cord from the electrical outlet and from the printer. Also unplug the interface cable.
3. Remove the face-up tray, if it is installed, by lifting it up slightly and pulling it out.
4. Move the printer and place the lower paper cassette in the location where you will operate your printer.
5. Lift the printer using the recessed handles on each side and hold it over the lower paper cassette. The printer is heavy, so you may need to have someone help you lift it.



Also, you may need to have someone help you align the holes on the printer with the pins on the cassette unit.

6. Make sure the front of the printer faces the same way as the front of the cassette. Then align the printer with the cassette using the two alignment pins, shown below. These pins fit into the two holes on the bottom of the printer. Lower the printer until it rests on the cassette unit.



7. Plug the power cord back into the printer and into an electrical outlet. Also re-attach the interface cable.
8. Turn the printer on. On the right of the display, you see both the size of paper in the standard cassette and the size of paper in the lower paper cassette unit.

READY:P LJ-3 LT A4

If you use letter size in the standard cassette and A4 size in the lower paper cassette, you see the display above. Two hyphens (--) in the display indicate that a tray is empty.

The Face-up Output Tray

The printer normally delivers paper face down on top of the printer. If you want face-up delivery, you can install the optional face-up output tray. This tray gives you immediate viewing of your printed output and is recommended for printing on media such as labels and overhead transparencies that require a straight-through paper path.


Installing the face-up output tray

1. Unpack both the tray and the static brush from the carton.
2. Turn off the printer.




WARNING: If you have used the printer recently, let it cool before you proceed.


3. Snap the static brush onto the upper edge of the face-up output slot shown below.



4. Slide the tray into the bottom of the face-up output slot so the notches on each side fit under the tabs on the side of the slot



The printer is factory set for facedown output. To select face-up delivery, set the paper path selector to the FACE UP position, as shown below.



Memory Options

The printer comes with 1MB of Random Access Memory (RAM). If you regularly print complex pages using graphics **or** downloaded fonts, you may need to increase your printer's memory. You can increase it up to **7.5MB**.

You have two options for adding memory to your printer:

- Increase the memory on the main controller board with **.5MB** memory chip sets. You can install up to two chip sets for a **total of 1MB** of additional **RAM (2MB RAM total)**.
- Add a OK memory expansion board and install up to four **2MB** chip sets and/or **.5MB** chip sets for a total of up to **6.5MB** of additional RAM (7.5 MB RAM total).

You can install memory on either the controller board or the OK expansion board or both.

There are two types of chip sets you can buy:

- **.5MB** chip sets each containing four **256Kbit X 4 80ns** DRAM **20-pin** DIP chips
- **2MB** chip sets each containing four **1Mbit X 4 80ns** DRAM **20-pin** DIP chips

You can install **.5MB** chip sets on the controller board or **the OK** expansion board; you can install **2MB** chip sets only on the OK expansion board.

Note: You can use the **0.5MB** or **2.0MB** expansion board (**C82201*** or **C82203***) in your printer with the following conditions:

- You must first increase the controller board's **memory** to its full **2.0MB** capacity.
- You can use only **0.5MB** chip sets to **fill** the expansion board.
- You do not need to change any DIP switches.

When to increase the printer memory

The printer displays one of these status messages when you have insufficient memory.

- **INSUFF MEMORY**
- **PAGE BUFFER FULL**
- **ADD MEMORY FOR CH X**

These messages are described in more detail in Chapter 6.

If one of these **messages appears**, you can **try** to reclaim any unused RAM by changing the settings for the SelecType **FULL PRINT** and **RX-BUFFER SIZE** options. See Chapter **3** for information on changing these options. If insufficient memory is still **a** problem, you can install additional **memory**, **as** described in this section.

Using an optional identity card **requires** at least **1.5MByte** of RAM.

Therefore, you must add at least **0.5MB** of additional RAM to your printer to use an identity card.

If you use the **INDIVIDUAL** setting in SelecType, each channel **requires** at least **0.5MB** of RAM. Therefore, if you plan to use more than two interface **channels**, you must add RAM to your printer.

Selecting a memory option

Before adding memory, you should determine the combination of components you need to use to obtain the total amount of memory you want. Keep in mind **that** your printer comes with **1MB** of internal memory.

If you need more **than 2MB** of RAM, you can install the OKB expansion board and use either **0.5MB** or **2MB** chip sets.

The table below **describes** the chip sets you can install on the controller board and/or the OKB expansion board.

OKB expansion board RAM configurations			Total RAM (internal, controller board, and expansion board)		
1	2	3	4	5	6
Install n 2MB chip sets	Install n 5MB chip sets	Total RAM on the expansion board	Controller board with no chip sets (1MB RAM)	Controller board with 1 chip set (1.5MB RAM)	Controller board with 2 chip sets (2MB RAM)
--	1	5MB	1.5MB	2MB	2.5MB
--	2	1MB	2MB	2.5MB	3.0MB
--	3	1.5MB	2.5MB	3MB	3.5MB
--	4	2MB	3MB	3.5MB	4MB
1	--	2MB	3MB	3.5MB	4MB
1	1	2.5MB	3.5MB	4MB	4.5MB
1	2	3MB	4MB	4.5MB	5MB
1	3	3.5MB	4.5MB	5MB	5.5MB
2	--	4MB	5MB	5.5MB	6MB
2	1	4.5MB	5.5MB	6MB	6.5MB
2	2	5MB	6MB	6.5MB	7MB
3	--	6MB	7MB	7.5MB	*
3	1	6.5MB	7.5MB	*	*

* If you install 6.5MB of memory on the OKB expansion board, you do not need to install any additional chip sets on the controller board; your printer can access a maximum of 7.5MB.

Installing additional memory

To install a memory chip set or a memory expansion board you need a cross-head **screwdriver** and a chip puller or a flat-head screwdriver. If you have questions about installing the chip set or the board, contact your dealer for assistance.




WARNING: High voltages are present inside the printer when the power is on. Do not attempt to remove the controller board **unless** the printer is turned off and the **power cord is unplugged**. Also, **try not to touch the contacts** on the printer's circuit board because many of the components can be destroyed by the static electricity **in your body**.

The rest of this chapter describes the procedures for installing a memory chip set and/or the OK expansion board.


Removing the controller board

1. Unplug the power cable from the electrical outlet and from the back of the printer.
2. Disconnect all interface cables from the back of the printer.


3. Remove the four screws that secure the metal bracket on the back of the printer. Keep the screws so you can use them to reinstall the controller board.



4. Press down on the lever at the bottom of the bracket to release the controller board, as shown below. **Press firmly** until the board pops out slightly.



5. Grasp the board with both hands and pull it straight out of its slot.




6. Set the controller board on a clean, stable surface with the bracket (connector) facing to your right and the components facing up.
7. If you have installed an optional interface card, you must remove it before you can **install a memory chip set** on the controller board. Grasp the interface card and pull it straight out of the interface slot.


Note: If you are installing chip sets on the controller board, you may want to remove the plastic guide rail above the **RAM chip sockets**. To do so, release the two tabs that secure the guide rail and lift it off the board. **Replace** the rail after you **install** the chips

Installing chip sets on the controller board

The RAM chip sockets are located on the upper right side of the controller board.




There are two sectors on the board, each containing four chip sockets (identified by their IC numbers), as shown below.



If both two sectors are empty, **install** the **first** chip **set** in sector 1. If sector 1 is already filled, install the second chip set in sector 2.


sector	IC number	Total RAM when filled
1	10, 11, 12, 13	1.5MB
2	14, 15, 16, 17	2MB




CAUTION: You cannot install a **2MB** chip set on the controller board: you can only use the **.5MB** chip sets.

Follow these steps to install a memory chip set:


1. Make sure all the pins on the chip are aligned. They should point inward at slightly **less** than a **90°** angle, as shown below.



- If any of the **pins** are bent incorrectly, **gently** push them back into alignment.
2. Line up the pins on the RAM chip with the holes in the socket. Be sure that the small notch on the end of **the** chip is toward your right.




3. Gently press the chip halfway into the socket. If it goes in at an angle, remove it with a chip puller or a small flat-head screwdriver; then reinsert the chip.



CAUTION: Be careful not to scratch the chip or the board when removing the chip.


4. Once the chip is properly inserted, push down firmly on both ends to make sure it is fully seated.



5. Repeat steps **1** through **4** for each of the remaining chips.
6. Reinstall the interface card, if necessary.

Installing chip sets on the memory expansion board


There are four sectors on the memory **expansion** board, each containing four chip sockets (identified by their **IC** numbers).




The four sectors must be filled in alphabetical order. For example, if you are installing your first chip set, install it in sector A. Then install your next chip set in sector B and so on. See the table under **"Selecting a memory option,"** earlier in this section, for a list of the RAM configurations possible the memory expansion board.

Before you install the chips, check their pin alignment as described in **step 1** of the previous **section**. Then follow these steps:

1. Place the expansion board on your work surface with the components facing up.
2. Align the chip's pins with the holes in the socket. Be sure the **small** notch on the end of the chip is facing in the direction shown below.



- Press the chip into the socket as described in steps 3 and 4 of the previous section.
- Set the board's DIP switches to indicate the amount of memory you have installed. Use a pointed object, such as a ball-point pen, to set the DIP switches as shown below.




Set the switches according to the tables below.

DIP Switch	RAM (internal and amount added to controller board)		
	1MB	1.5MB	2MB
1	OFF	ON	ON
2	ON	OFF	ON


DIP Switch	Sector	ON	OFF
3	A	2MB	.5MB
4	B	2MB	.5MB
5	C	2MB	.5MB
6	D	2MB	.5MB

Installing the expansion board on the controller board

- Locate connector **CN3** on the controller board. position the memory expansion board as shown below, and carefully insert its connector into connector **CN3**.




- Secure the expansion board with the three screws that came with it.




Reinstalling the controller board

- Hold the controller board so the component side faces your left, and fit its top and bottom edges into the grooves inside the slot. Gently slide the **board** about halfway **into the printer**.




- Make sure the lever on the bottom of the controller board is **all the way down**. As you slide the board further into the printer, make sure the lever's tab is positioned inside the opening in the bracket, as shown below.



- Now slide the controller board into the printer. **The lever pivots outward. Firmly press up on the lever to lock the board into place.**

If the controller board does not fit smoothly into the printer, do not force it. Remove it and make sure the edges fit properly into the grooves in the slot.

- Gently press in on the **board** to make sure it is fully seated. Then secure the **board** with the four screws you removed previously.



- Replace the optional interface card, if you removed one
- Connect any interface cables you removed.
- Be sure **the power** is turned off and then plug the power cord into the printer and into an electrical outlet.

Lower paper cassette unit

AC power supply: DC **24 V** supplied by the printer

10 M ohm minimum

Can withstand 1000 VAC **rms (120V model)** or
1500 VAC **rms (220/240V model)** for one minute

12 W *or* less

Weight: **60** to 90 **g/m²** (16 to 24 lb)

Paper feed: Automatic feed delivery system; tray capacity up to 250 sheets (75 **g/m²** or **20** lb paper)

Feeding speed: For first sheet, **18** seconds or less (A4 or letter-size paper)
For subsequent sheets, up to **10** pages per minute (M-sire paper)

Types: Plain paper, such as copier paper, memo sheets, and letterheads

Dimensions and weight (without the printer)

Height: 70 mm (2.8 inches)
Width: **480 mm (19 inches)**
Depth: **370 mm (15 inches)** including the standard cassette
Weight: 3.8 kg (**8.4 lb**) including the standard cassette

Dimensions and wright (without the printer):

Height: **40 mm (1.6 inches)**
Width: **255 mm (9.2 inches)**
Depth: **255 mm (11.2 inches)**
Weight: **0.3 kg (0.7lb)**

50 sheets (80g/m²)HP **LaserJet III** emulation mode

When your printer is in HP LaserJet **III** (LJ-3) mode, the factory setting, select one of the following drivers from your program's **printer** selection menu:

HP LaserJet **III**Si™
HP LaserJet **III**PTM™
HP LaserJet series **III**™
HP LaserJet **II**PTM™
HP LaserJet series **II**™
HP LaserJet **Plus**™
HP LaserJet **500**™
HP LaserJet™

Epson LQ and FX emulation modes

When your printer is in the Epson LQ or FX printer mode, select one of the following drivers from your program's printer selection menu:

LQ-2500	FX-1000/800 (286e/86e)
LQ-1050/850	FX-85
LQ-1000/800 (expanded ESC/P)	FX-80
LQ-500	
LQ-1500 (with version 2 ROM)	
LQ printer	

If **none** of the printers listed are available **from** your program, choose the first **available of the following**: RX, Epson **printer**, Standard printer, or Draft printer.

You can connect your printer to as many as three different computers at the same time using any combination of the parallel, serial, and optional interfaces. Simply connect interface cables from the computers to the interfaces.

If you **use** the default printer mode LJ-3 for **all** the interfaces, that's **all** you need to do unless you need to change serial interface settings. If you wish, however, you can choose different printer modes for each interface, **and** you can allocate a **separate** pdrt of the printer's memory for each interface.

Your printer receives data from the computers through the following channels:

Channel P is the **parallel** interface.
Channel S is the serial interface.
Channel 0 is the optional interface.

This section contains an alphabetical list of status and error messages that you **may** encounter and includes likely solutions to problems.

If an error occurs, the control panel displays an error messages that **tells you what** is wrong and, in some cases, offers a solution. Status **messages also appear** on the display during **normal** operation; they indicate the printer's current **status**.

Note: In some cases, the red CONTINUE light flashes when an error is detected. This requires you to correct the problem and then press the **CONTINUE** button to clear the error. **However, if** the AUTO CONT option in **SelectType** is set to ON, some errors may clear automatically **even though the problem** remains.

In this section, status messages are preceded by [S], warning messages are preceded by [W], and error messages are preceded by [E]. In some cases the message you see on your display **also shows** the printer mode.

[E] ADD MEMORY FOR CH:

The printer has insufficient memory available in the channel displayed. You may have changed the printer mode, increased the RX-BUFFER **SIZE** setting, or changed the CH INDIVIDUAL setting. To correct the error, decrease the **RX-BUFFER SIZE** setting or change the CH INDIVIDUAL setting in SelecType. Changing the CH setting from INDIVIDUAL to AUTONSENSE may solve this problem. If necessary, add memory to your printer.

[W] CANCEL MANUAL FEED

There is no **paper in** the manual-feed tray when you have selected manual feed. To cancel manual feed, **press the MANUAL** button to feed **paper** from the cassette. This message alternates with the SET MANUAL message.

[E] CARD MEMORY OVERFLOW

This message indicates that the combined memory of the **cards** in slots A or B exceeds **4MB**. Remove one or both of the **cards** and press the CONTINUE button.

[S] CHARCREATING

The printer is creating characters.

[S] COPY END XXX

Multiple-copy printing is canceled (you pressed the **COPY** END button with the printer off line).

[E] COVER OPEN

The **printer's cover is open**. Close the printer **cover** to continue printing.

[S] DATA

The printer has **received** data but is not yet printing, or is off line. To **resume printing**, press ON LINE if the printer is off line, or **press FEED**.

[E] FEED JAM

Paper is not feeding into the printer from the specified cassette or has jammed on its way into the printer. If the paper **is** jammed at the paper cassette, open the printer case, remove the jammed paper from the standard paper cassette or optional **paper cassette** and then close the printer's covers.

[S] FONTCREATING

The printer is **creating** a font.

[S] GRAPHICDRAWING

The printer is composing a graphic.

[E] ILLEGAL CARD

The printer cannot read the card **inserted** in the slot indicated on the **display**. To correct the error, press CONTINUE. If the error message remains, make sure the printer is off line and remove the card. If the red **CONTINUE** light still flashes, press CONTINUE.

[S] INITIALIZE

The printer is being initialized to the factory settings.

[E] INSERTIMAGING CRTG

The imaging cartridge is not installed.

[E] INSERTTRAY


The standard paper cassette is not installed.

[E] INSUFFICIENT MEMORY

The printer **has** insufficient memory available for the current task. To correct the error, press CONTINUE. If the message remains, press **RESET** or initialize the printer.

You can also clear this error by turning the **printer off and back on again**. However, **it may be necessary to simplify** the page you are trying to print or add more memory to the printer.

[E] INVALID ASSIGN

If you assign PostScript to more than one channel, this message appears when you attempt to exit from SelecType. Press  to return to MODE ASSIGN and change the assignments.

[E] PAGE BUFFER FULL

Text or graphics data has filled the printer's buffer and the printer has ejected an incomplete page. Press CONTINUE to **clear** the error. You may need to add more memory to your printer.

[S] PAPER FEEDING

The printer is feeding paper.

[E] PAPER JAM

Paper is not being fed into the printer or paper is jammed in the paper path. **Open** the printer and clear the jammed paper as described later in this chapter.

[E] PAPER OUT

There is no paper in the standard paper cassette or the optional lower **paper** cassette (if installed). Load more paper into the selected paper cassette.

[E] PAPER OUT AUTO XXX

There is no paper in the standard cassette or the optional lower paper cassette (if installed). The display prompts you to load paper **into** the specified cassette.

[E] PAPER OUT OPT XXX

There is no paper in the optional lower paper cassette. The display prompts you to load the correct paper size into the lower paper cassette.

[E] PAPER OUT STD XXX

There is no paper in the standard paper cassette. **The** display prompts you to load the **correct** paper size into the cassette.

[S] PRINTING

The printer has received data and is printing.

[S] PRINTSTOPXXX

The printer stops printing during the multi-copy print operation.

[S] ESCAPE

The printer is using the intelligent **emulation** switch and is not in a timeout status. It can use either one of the modes shown on the display.

[S] RAMCHECK X.X ME

The printer is checking the available RAM (X.X = capacity).

[S] READY

The printer is ready to print.

[E] REINSERT CARD

You may have removed an option card while the RED light was still lit or while the printer was on line. To correct the error, make sure the printer is off line. Next, reinsert card into the correct slot and press **CONTINUE**.

[E] REMOVE CARD

You may have inserted an option card while the printer was on line or while the FEED light was on. Data still remains in the printer's Buffer. To correct this error, take the printer off line. Then remove the card and press **CONTINUE**. Before you reinsert the card, make sure that all data in the buffer has been printed and that the printer is off line. If the FEED light is on, press **FEED** to print any remaining data.

[E] RESELECT TRAY

The optional lower paper cassette unit is not installed and the **INPUT** option is set to **OPT** or **AUTO**. Turn off the printer and install the optional lower paper cassette unit. If you decide not to use the optional paper cassette unit, press **CONTINUE** to select paper automatically from the standard paper cassette. After printing, change the **INPUT** option to **STD**.

[S] RESET

The printer has been reset to the macro specified with the **SelecType** **LOAD MACRO** option.

[S] ROM Check

The printer is checking ROM.

[E] SAVE MEMORY OVERFLOW

This message may appear when you are trying to save a macro with the **SAVE MACRO** option. The printer does not have enough memory to save the macro. To correct this error, delete unused macros using the **DELETE** **MACRO** option.

[E] SERVICE REQ. CXXXX

A controller error has been detected. Write down the error number listed on the display and turn off the printer. Wait at least five seconds and then turn it back on. If the error message still appears, turn off the printer, unplug the power cord, and contact a qualified service person.

[E] SERVICE REQ. E00XX

A print engine error has been detected. Write down the error number listed on the display and turn off the printer. Wait at least five seconds and then turn it back on. If the error message still appears, turn off the printer, unplug the power cord, and contact a qualified service person.

[E] SET FULL PRINT

This message may appear when you are trying to print graphics or a mix of text and graphics. Press **CONTINUE** and then change the **SelecType** **FULL PRINT** setting.



[W] SET MANUAL

There is no paper in the manual feed tray and you have selected manual feed. Load a sheet of paper in the manual feed tray. To cancel manual feed, press the **MANUAL** button to feed paper from the paper cassette. This message alternates with **CANCEL** **MANUAL FEED**.

[S] STANDBY MODE

If all of the channels received no data for about thirty minutes and you enabled the **STANDBY** mode in **SelecType**, the printer enters standby mode. Press any panel button or send data to warm up the printer.

[E] START UP ERROR

If this message appears when you turn on the printer, the power may have been turned off while the printer was performing a save operation. To clear this error, press  or  to return the printer's default settings to **LT** or **A4** paper, respectively.

[W] TONER LOW

The printer is almost out of toner. When you see this message, you can still print up to 25 more pages. You must replace the imaging cartridge soon.

[E] TONER OUT

You must replace the imaging cartridge.

[E] TRAY SET AUTO XXX

The paper size setting does not match the paper loaded in the specified paper cassette. The display indicates the expected paper size and the currently selected cassette. You can either change the paper size setting or load the correct paper size. After you correct the paper mismatch, press **CONTINUE**.

[E] TRAY SET OPT XXX

The specified paper size does not match the paper loaded in the optional lower paper cassette. The display indicates the expected paper size. After you correct the paper mismatch, press **CONTINUE**.

[E] TRAY SET STD XXX

The specified paper size does not match the paper loaded in the standard paper cassette. The display indicates the expected paper size. After you correct the paper mismatch, press **CONTINUE**.

[S] WARMING UP

Printer is warming up.

SelecType

The **SelecType** function on the printer control panel allows you to control most of the printer's functions, such as printing test pages, selecting paper size, and changing the printer's configuration.

SelecType is divided into two levels: Level 1 and Level 2. Level 1 contains everyday printing and font selection functions, and Level 2 contains functions that you are less likely to change frequently, such as printer mode and printer configuration.

Your application program may send printer commands that override the **SelecType** settings. If you are not getting the results you expect, check your application software settings.

Note: New **SelecType** settings are in effect only until you turn off the printer unless you save them with the Level 1 **SYSTEM** **CONFIG** option or the Level 2 **P-CONFIG** **SAVE** option.

Level 1 functions

S: P: Q:	Selects the serial, parallel, or optional channel when you have set up more than two interfaces and used the INDIVIDUAL mode.
INPUT	Selects the standard or optional paper cassette.
PAGE SIZE	Specifies the size of paper.
COPIES	Selects the number of copies to be printed.
ORIENT	Selects the printing orientation: portrait (vertical) or landscape (horizontal).
FONT	Selects one of the fonts available in the current printer mode.
STATUS SHEET	Prints a report listing the current printer settings.
FONT SAMPLE	Prints a sample of the fonts available in the current printer mode.
SUB CONFIG	Defines the printer's subconfiguration; depending on the printer mode, controls such features as symbol set and number of text lines.
SYSTEM CONFIG	Defines the printer's system configuration; saves Level 1 settings, displays the amount of memory remaining, changes top and left offsets, and enables printing of complex pages.

Level 2 functions

TEST PRINT	Prints two test patterns to check the printer's operation.
MODE ASSIGN	Chooses one of the emulation modes: HP LaserJet III, Epson LQ, Epson FX, or IES modes. In the IFS modes, the printer switches automatically between PostScript and another mode (if PostScript is available). With an optional identity card, you can also select Epson GL or PostScript emulation.
IF CONFIG.	Configures the parallel and serial interfaces.
RX-BUFFER SIZE	Chooses the size of the receive buffer.
CH	Selects the AUTONSENSE or INDIVIDUAL mode and assigns memory for INDIVIDUAL
TIMEOUT	Defines the auto emulation switch timeout; if no more data is sent during the specified time period, the printer switches from one emulation mode to the other.
CH TIMEOUT	Defines the channel timeout; if no data is sent during the specified time period, the printer switches from one channel to the other.
PAUSE CONT	Selects automatic continue, which permits the printer to continue printing instead of stopping after certain error conditions occur.
BEEPER	Turns the beeper on or off.

F-CONFIG SAVE Saves the printer's configuration; saves **all Level 2** settings as defaults so they **take** effect each time you turn on the printer.

FACTORY RESET Returns **all** Level 1 and Level 2 settings to their factory settings.

VERSION Displays the **version** numbers of the printer's firmware components such as controller and font.

PAGE COUNTER Displays the total number of sheets printed by **the** printer.

RITech Selects one of the settings for Epson's Resolution Improvement Technology, which produces smooth text and graphics.

STANDBY Conserves energy by reducing power to the **fixer** heater when the printer is not in use for **30** minutes.

Printing a Status Sheet

In addition to the test print patterns, you can print a status sheet that lists the **current** printer **settings**.

Note: The status sheet lists the printer's current settings. If you **change** the macro number setting for the LOAD MACRO option in the SYSTEM CONFIG submenu, the status sheet prints out the new **macro** settings. MACRO 0 is the factory default setting.

Follow these steps to print the status sheet:

1. Press SelecType once to enter SelecType Level 1.


Note: If you have already chosen the INDIVIDUAL mode in SelecType and have set up more than one channel, the following option appears on the display (The display shows **available channels** only):

CANCEL:◀ S: P: Q:▶

Press any arrow button to choose your channel; then go on to step 2.

2. Press  until **STATUS SHEET** appears on the display.

◀STATUS SHEET▶

3. Press  twice to print the status sheet.

4. Press the SelecType button twice to exit SelecType.

A portion of tk status sheet printout is shown below.

Printer Configuration		STATUS SHEET	EPSON
Installed Memory	: 4.5Mbytes	Controller Version	: 21.04
Memory Share	: AUTOSHARE	CH Time out	: 60
Auto Continue	: OFF	Total Printed Count	: 583216
Standby	: DISABLE	Beeper	: ON
System	: 22.17	Version	: 22.17
Mode Configuration			
Input Tray	: AUTO A4	Font	
Copies	: 1	Orientation	
Sub Configuration			
Form Length	: 64	Symbol Set	: Roman-8

Data Dump Mode

Data dump mode is a special feature that makes it easy for experienced users to find the cause of communication problems between the printer and computer. In data dump mode, the printer produces as exact printout of the codes it receives.

- 1. Make sure that paper is loaded and the printer is off.
- 2. Hold down the SelectType button while you turn on the printer. Make sure you hold the button down until you see message HEX DUMP on the display.
- 3. Next, run any program that causes the printer to print (either an application program or a program written in any programming language). Your printer prints out all the codes it receives in hexadecimal format, as shown below.

***** HEX DUMP LIST **	PAGE	1
0000 18 52 10 18 43 45 18 88 00 18 70 00 18 83 0C 18	..R..CE..K..p..c..	
0001 74 01 18 32 54 72 6F 75 62 8C 65 20 73 88 6F 6F	t..2Trouble shoo	
0002 74 69 6E 67 20 20 20 20 00 0A 54 88 68 73 20	ting ..This	
0003 63 68 61 70 74 65 72 20 64 68 73 63 75 73 73 65	chapter discuss	
0004 73 20 70 72 6F 62 6C 65 60 73 20 79 6F 75 20 6D	s problems you m	
0005 61 79 20 65 6E 63 6F 75 6E 74 65 72 20 61 6E 64	ay encounter and	
0006 20 74 68 65 69 72 20 6C 69 68 65 6C 79 20 73 6F	their likely so	
0007 6C 75 74 69 6F 6E 73 2E 20 00 0A 00 0A 48 66 20	lutions.If	
0008 61 6E 20 65 72 72 6F 72 20 6F 63 63 75 72 73 2C	an error occurs,	
0009 20 79 6F 75 72 20 62 65 73 74 20 73 6F 75 72 63	your best sourc	
000A 65 20 6F 64 20 69 6E 64 6F 72 6D 61 74 68 6F 6E	e of information	
000B 20 00 0A 68 73 20 74 68 65 20 64 68 73 70 6C 61	..is the displa	
000C 79 20 6F 6E 20 74 68 65 20 63 6F 6E 74 72 6F 6C	y on the control	
000D 20 70 61 6E 65 6C 2E 20 00 0A	panel. ..	

- 4. To turn off the data dump mode and stop printing, press ON LINE to set the printer off line. (If you press ON LINE while a page is being printed, the green ON LINE light flashes until the page is ejected and the printer goes off line.) To exit the data dump mode, turn off the printer.

Look at the sample data dump printout. By reading the characters printed in the text field on the right side of the data dump printout or the printout of hexadecimal codes, you can check what codes are being set to the printer. In the text field, printable characters appear as their true ASCII characters. Non-printable codes, such as control codes, are represented by dots.

To interpret a data dump printout, look at the first two hexadecimal codes on line 0004 of the printout sample (73 to). Code 73 represents the letter s; code 20 represents a space. Check the fifth line of the text field on the right side of the printout and you will find the letter s followed by a space.

Information Reference List

Engineering Change Notices

None.

Product Support Bulletins

None.

Technical Information Bulletins

None.

Related Documentation

TM-EPL8000	EPL-8000 Service Manual
PL-EPL8000	EPL-8000 Parts Price List
SPKEPL8000	EPL-8000 Self Paced Kit
4000834 G01-00	EPL-8000 User's Guide
4000835 G01-00	EPL-8000 Quick Setup & Maintenance Guide